

BANNERS

USE AND CARE INSTRUCTIONS

- **Banner Storage**

Make sure banner is clean and dry. Roll with image facing out.

Store in or on a cardboard tube

DO NOT FOLD

Store at room temperature.

- **Cleaning**

Mild soap and water and dry completely with a soft cloth.

Solvent or harsh cleaners (windex) will damage the vinyl or inks used on the banner.

- **Post installation**

For installation between 2 posts - starting with the top, attach the rope to first post, weave the rope through all the grommets provided, keeping the rope taught secure to the second post, repeat for the bottom. Next secure the corners with rope to keep the banner taught.

Do not hang the banner from the corners only, as this may cause damage to the banner.

- **Frame Installation**

For a long term option, consider a frame (sold separately), build your own using pvc pipe or wood, or ask a sales representative for other options.

- Damaged banners can most likely be repaired (grommets replaced, tears repaired)

JACK RABBIT SIGN SHOP IS NOT RESPONSIBLE FOR DAMAGE TO BANNERS DUE
TO ERRORS IN INSTALLATION OR IMPROPER CARE.
FOR PROFESSIONAL INSTALLATION, CONTACT YOUR SALES PROFESSIONAL.

